



2 - PIECE POGO POLE ONE-TIME ASSEMBLY INSTRUCTIONS

USERS MANUAL



PART NUMBER: FG0040

UPDATED 03/17/2017

Division of D.P.L. Enterprises, Inc.
3868 East Post Road, Las Vegas, Nevada 89120, (702) 454-5515, FAX (702) 454-5225
Website: www.air-care.com; Email: Info@air-care.com

Pole Assembly

The Pogo Pole Hose adapter consists of the adapter plate with 12" collar and fork and 2 poles that slide inside the other. The Pogo Pole Hose is shipped in 4 pieces.

The 2, five foot poles are shipped as 2 pieces each, 32" long for the 3/4" diameter and the 1-1/8" diameter. They are each 62" long when assembled.

Part No.	Description	Quantity	Notes
COM0623	3/4" Dia., swaged top pole, w/ holes	1	Top pole, inner, connects to fork ASM. The spring and washers are installed on it.
COM0624	3/4" Dia. pole with holes, not swaged	1	Bottom pole, inner.
COM0625	1-1/8" Dia., swaged top, open bottom	1	Outer pole top
COM0626	1-1/8" Dia., swaged top, rubber foot on bottom	1	Outer pole bottom
COM0236	6-32 x 3/16 L, Flat head undercut, Phillips Head, SS Screw	6	Only 4 are needed, 2 are spares.

Assembly: 3/4" dia Poles (Smaller Diameter)

Locate COM0623 (The smaller pole with the spring installed at one end and other end is swaged to fit inside another small pole). The end has small threaded hole that goes all the way through and a larger hole without threads.

Locate COM0624 (The smaller pole that is NOT swaged). Note the location of the holes in one end that are countersunk for the flat head screws.

Insert the swaged end of COM0623 into the end of COM0624 that has the matching Holes. Align the holes in the swaged end with the countersunk holes in the non swaged end.

Install a screw (NBS0236) into each hole and tighten securely, but DO NOT OVER TIGHTEN.

Remove the 10-24 nut and screw that hold the spring in place, and slide the 5/8" Dia. Pin from the adapter plate fork into the end of this pole with the spring on it. Align the hole in the pin with the hole in the end of the pole and reinstall the screw and attach the nut. Tighten securely.



Assembly: 1-1/8" Dia Poles (Larger Diameter)

Locate COM0625 - Larger diameter pole with swaged end that has 2 threaded holes in the swaged end and a rubber crutch tip on the other end. This is the bottom pole section.

Locate COM0626 - Larger diameter pole with 2 countersunk holes in the NON-SWAGED end.

Insert the swaged end with the threaded holes into the UNSWAGED end of the other pole with the countersunk holes. Align the holes as you insert them.

Install a screw into each hole and tighten securely, but DO NOT OVERTIGHTEN.

Slide the open end of this larger pole assembly over the end of the smaller pole with the fork and adapter plate.

Full instructions on using the pogo pole hose adapter are in the Online User Manual.

